



TIKITM
ARMOR

Installation Instructions

Tools Needed:

- Razor knife
- Masking tape
- Roller (available at home centers)
- Ammonia-based window cleaner (Windex® brand is best)

Notes:

- Do not install if the temperature is below 60 degrees. The surface needs to be completely clean and free of any residues (oil, wax, etc.). The floor surface also needs to be completely dry in order to adhere properly.
- Do not pull or stretch pieces while installing.



1 Completely wash and dry the entire area where installation will occur.



2 Lay all pieces into their proper area for installation and check for fit and alignment. Once you are happy with the fit it is time to install. We suggest beginning at either the front or back and working towards the other direction.



3 Score the backing paper on the first piece to be installed in the middle of the mat using your razor knife. Be careful not to cut too deep.



4 Once the piece is in place and backing paper fully removed press down on the entire surface to ensure bond. Now take your roller and roll in a back and forth motion from the center of the piece, working your way to the outside. Apply even pressure. If you get a small bubble that will not work itself out you can poke a hole in the mat with a pin or the point of your razor knife and push the air out through the hole. The hole will be invisible once it is pressed down. Be sure to pay special attention to all the edges of the mats, making sure to press firmly all the way around. The pressure sensitive adhesive (PSA) on the back of the mats requires 15 psi to activate.



5 Continue with the rest of the areas to be covered with mats using the same method, and ensuring alignment of each piece before sticking them down. Enjoy your new look for your Island Time activity!